XINMENG新盟

M75

Mechanical Keyboard

微信扫码关注
了解更多资讯
SCAN THE WECHAT QR CODE TO
FOLLOW US FOR MORE UPDATES
新盟官方公众号

生产厂商:东莞市智达视电子有限公司
生产址:广东省东莞市石排镇沙角金沙二路38号1号楼
电　　话:0769-81829716/81829736
传　　真:0769-81829756
网　　址:http://www.szxinmeng.com.cn
执行标准:GB/T14081-2010
中国制造:MADE IN CHINA

Manufacturer:Dongguan Zhidaming Electronics Co.
Address:Building 1, No.38, Jinsha Road 2, Shajiao, Shipai Town,
Dongguan City, Guangdong Province, China
Website:http://www.szxinmeng.com.cn
Execution standard:GB/T14081-2010
MADE IN CHINA

SZXINMENG.COM.CN

新盟官方公众号

微信扫码关注
了解更多资讯
SCAN THE WECHAT QR CODE TO
FOLLOW US FOR MORE UPDATES

PMU-M75EYXN01

中文

M75无屏有线键盘说明书

产品适用范围:

新盟M75有线键盘，设计81键带VR功能及ARGB-灯光，产品都可运行于电脑Windows2000,WindowsXP,Vista,Win7,Win8,Win10,WIN11, OS2-2.0版本以上.

硬件要求:

带有电脑并有连接设备可以的USB接口

单模式连接示意图

键盘开关/接口说明



❶ TYPE-C连接端口
❷ MAC与Win系统切换开关

有线连接模式



M75有线键盘安装步骤及使用

FN+TAB=一键常亮白光	FN+"|\"=切换灯光效果模式
FN+DEL=切换灯光颜色	FN+ESC=键盘恢复出厂设置
FN+"+-/→"=灯光呼吸速变化快慢调节	FN+"↑/↓"=灯光亮度加减调节
FN+BackSpace(退格键)=一键开关灯-按一次关再按一次开	

M75有线键盘安装步骤及使用

1、使用M75有线机械键盘时，请把键盘配备的USB-TO-TYPE-C连接线取出，把USB头插到电脑的USB端口上，TYPE-C头插到键盘的端口上，只要在插好线的状态下电脑会自动完成安装相关软件，并可以使用。

2、键盘左上方靠右边设有Win系统和Mac系统切换开关，当切换开关处在Win位置时，则表示键盘适合是在Windows系统操作，当切换开关处在Mac位置时，则表示键盘适合是在Mac系统操作。

键盘支持灯光效果模式具体有:

随波逐流(-默认)、峰回路转、一触即发、一石二鸟、涟漪扩散、川流不息、重峦叠嶂、斜风细雨、来回穿梭、静态恒亮、单键点亮、单键熄灭、繁星点点、漫天飞雪、百花争艳、动态呼吸、光谱循环、彩泉涌动、多彩纵横、彩虹风车，七彩聚拢，霓虹叠影，关闭背光-依次循环切换。

键盘支持灯光颜色具体有:

彩虹色-红色-橙色-黄色-绿色-青色-蓝色-紫色-白色-共九种颜色。

键盘FN组合键功能:

FN+PGUp=INS键	FN+Win键=锁Win-键符灯变白光，再按退出恢复原灯光模式
FN+PGDn=END键	

M75键盘在WIN系统时FN多媒体功能键说明:

FN + F1=电脑屏幕亮度-	FN + F2=电脑屏幕亮度+	FN + F3=Calculator（计算器）
FN + F4=我的电脑	FN + F5=播放器	FN + F6=上一曲
FN + F7=下一曲	FN + F8=播放/暂停	FN + F9=停止
FN + F10=静音	FN + F11=音量-	FN + F12=音量+
FN + WIN=锁WIN键《这时WIN键符灯变白色提示》再按一下解除		
CAP-Lock键灯=按一下作用时键符灯变白光，再按一下恢复		

M75键盘在MAC系统时FN多媒体功能键说明:

F1=电脑屏幕亮度-	F2=电脑屏幕亮度+	F3=Ctrl+"↑"
F4=呼出siri(ALT+空格键)	F5=Ctrl+"↓"	F6=搜索（Command+Space）
F7=上一曲	F8=暂停/播放	F9=下一曲
F10=静音	F11=音量-	F12=音量+
注意：WIN/ALT会在切换界面时互换，不要锁win		

FN+F1=F1	FN+F2=F2	FN+F3=F3
FN+F4=F4	FN+F5=F5	FN+F6=F6
FN+F7=F7	FN+F8=F8	FN+F9=F9
FN+F10=F10	FN+F11=F11	FN+F12=F12

VR钮-操作说明

1.支持灯光模式切换，每按压一次切换灯光模式一次-一直循环，左右转动是调节灯光明暗或变化快慢(在长亮灯光模式时-能调灯光明暗在呼吸灯光模式时能调快呼吸快慢。)

2.FN+按压VR钮切换到多媒体模式。这时按压VR钮是播放或静音。左右转动是播放音量大小作用。再FN+按压VR钮又切换到灯光模式调节如此循环。

注意事项:

1、当使用键盘电脑无法识别使用时，应考虑端接触不良造成，需要更换插另一个电脑USB端口使用。

2、当产品在使用中出现卡顿或某一个键符没功能或不动时，应考虑是轴脚松动，有可能是多次插拔接触不良造成，应把这轴拔出来看轴脚有无插弯造成，在排除上述的原因外，如还是不能解决，请拨打新盟产品服务热线:400-006-1358解决。

3、新盟品牌的产品都是电子塑胶产品，所以为了产品性能稳定及使用者安全，产品只能在室内常温下使用请不要在高温或靠近火源地方使用。

4、产品损坏丢弃处理:如产品损坏不能修复时，请勿自行拆解或丢到火中，以免发生意外危险。应送专业废品处理站或专用回收箱进行处理。

物品清单:

1、TYPE-C充电连接线x1
2、说明书保修卡x1
3、拔轴拔键二合一工具x1

English

M75 Wired Keyboard without Screen User Manual

application scope of the product:

The Xinmeng M75 wired keyboard features an 81-key design with VRfunctionality and ARGB lighting, and is compatible with computers runningWindows 2000, Windows XP, Vista, Windows 7, Windows 8, Windows 10,Windows 11, and OS2 version 2.0 or above.

hardware requirement:

A USB port that comes with a computer and can connect to devices

Single-mode connection:

Keyboard switch/interface description



M75 Wired Keyboard Installation Steps and Usage

FN+TAB=One-click constant white light	FN+'|'=Switch lighting effect mode
FN+DEL=Switch light color	FN+ESC=Reset keyboard to factory settings
FN+"←/→"=Adjust the speed of light breathing or changes	FN+" ↑ / ↓ "=Adjust the brightness of the light up or down
FN+BackSpace=One-button light switch = press once to turn off, press again to turn on	

M75 Wired Keyboard Installation Steps and Usage

1. When using the M75 wired mechanical keyboard, take out theUSB-to-Type-Ccable that comes with the keyboard, plug the USB end intoyour computer's USBport, and plug the Type-C end into the keyboard. Onceconnected, your computerwill automatically install the necessary software,and the keyboard will be ready touse.

2. There's a Windows/Mac switch on the upper left of the keyboard, slightly totheright. When the switch is on the Windows position, the keyboard is set upfor usewith a Windows system. When it's on the Mac position, the keyboardis set up foruse with a Mac system.

The keyboard supports various lighting effect modes, including:

Go with the flow (default), take a different path, be on the verge of something, bejust on the cusp ofsomething, spread ripples, flow continuously, rise up mountainsand fall down valleys, gentle breeze anddrizzling rain, shuttle back and forth, remainconstantly bright in a static state, light a single key, turn offa single key, numerousstars twinkling, snow falling all over the sky, various flowers competing forbeauty,dynamic breathing, spectral cycle, colorful water flowing, diverse andextensive, rainbow windmill, con-vergence of seven colors, neon overlapping-shadows, turn off the backlight cycle through and switch insequence.

The keyboard supports specific lighting colors as follows:

The rainbow colors - red, orange, yellow, green, cyan, blue, purple, white total nine colors.

Function of the FN combination keys on the keyboard:

FN+PGUp=INS	FN+Win=The Win+key indicator light turns white, and pressing "Escape" restores the original lighting mode
FN+PGDn=END	

M75 keyboard's description of the FN multimedia function keys in the WIN

FN + F1=Computer screen brightness-	FN + F2=Computer screen brightness+	FN + F3=Calculator
FN + F4=My Computer	FN + F5=Iplayer	FN + F6=Previous track
FN + F7=Next Track	FN + F8=Play/Pause	FN + F9=Istop
FN + F10=Mute	FN + F11=Volume-	FN + F12=Volume+
FN + WIN=Lock the WIN key (at this time, the WIN key indicator light turns white for prompt) and press it again to unlock		
CAPI-Lock=Press once to turn the function key light white, and press again to restore		

M75 keyboard's description of the FN multimedia function keys in the MAC

F1=Computer screen brightness-	F2=Computer screen brightness+	F3=Ctrl+↑↑
F4=Call Siri (ALT+Spacebar)	F5=Ctrl+↑↓	F6=Search (Command+Space)
F7=Previous track	F8=Pause/Play	F9=Next Track
F10=Mute	F11=Volume-	F12=Volume+
Note: WIN and ALT will be interchanged when switching interfaces, so do not lock the win key		

FN+F1=F1	FN+F2=F2	FN+F3=F3
FN+F4=F4	FN+F5=F5	FN+F6=F6
FN+F7=F7	FN+F8=F8	FN+F9=F9
FN+F10=F10	FN+F11=F11	FN+F12=F12

VR button function description:

1. Supports switching light modes. Each press changes the light mode once—in a continuous loop. Turning left or right adjusts the brightness or speed of the light changes (in steady light mode, you can adjust brightness, in breathing light mode, you can adjust the breathing speed).
2. Press the VR button with FN to switch to multimedia mode. At this time, pressing the VR button plays or mutes audio. Turning it left or right adjusts the volume. Pressing FN + VR again switches back to light mode, and this cycle repeats.

NOTES

1. If your keyboard isn' t recognized when connected to the computer, it might beduе to poor contact at the connector. Try plugging it into another USB port.

2. If the keyboard lags during use or a specific key isn' t working, it could be that theswitch stem is loose, possibly from being plugged in and unplugged many times. Trypulling out the switch stem and check if the pins are bent. If this doesn' t solve theissue, please call Xinmeng product service hotline at 400-006-1358.

3. Xinmeng products are all electronic and plastic, so to keep performance stable andensure user safety, they should only be used indoors at normal temperatures. Avoidusing them near high heat or open flames.

4. Handling damaged products: If the product is broken and cannot be repaired, donot disassemble it yourself or throw it into a fire to avoid accidents. It should be takento a professional recycling station or placed in a designated recycling bin for properdisposal.

List of items

1. TYPE-C charging cable x1
2. One instruction manual and warranty card
3. One 2-in-1 switch puller and keycap puller tool

新盟产品质量保证卡

承蒙惠购新盟产品，谨致谢意！为了让您放心使用本产品，更好地保护您的权益，我公司在严格实行国家质检总局联合信息产品部以及国家工商行政管理局共同签发的《微型计算机商品修理更换退货责任规定》的基础上实行售后服务，特作出如下承诺：

一、服务有效期：

自购买之日起生效，即以本凭证记载的日期为准。

二、服务内容：

■自购买之日起7日内，包装未损坏，不影响再次销售的产品，消费者不满意，包退包换。
■自购买之日起15日内，消费者不满意，包换同档价值之新盟产品。
■自购买之日起，由电气性能不良引起的产品故障，在质保期内，免费进行维修。(维修具体事宜由所在区域之新盟产品省代或新盟产品总公司处理)

三、不属于服务之范围：

■已经超出有效服务或免费维修期限的。
■未按正确使用说明使用，维护，保管导致故障或损坏的。
■非新盟产品授权维修机构维修而导致的故障或损坏。
■三包凭证上无经销商登载资料及盖章之产品。
■擅自涂改三包凭证内容的。
■消费者自行拆除产品底部QC PASS贴纸之产品。
■由于不可抗力(如地震、火灾、水灾)原因造成产品之不良。
■人为因素造成之产品不良(如操作失误，搬运损坏，磕碰，输入不合适电压等)。
■其他非产品设计，技术，制造，质量等问题而导致的故障或损坏。

四、联络方式：

新盟产品售后服务承诺，实行全国联保，新盟产品各省级代理及分公司有义务履行承诺。
新盟产品客服热线: 400-006-1358

注:本承诺中电话号码若有变更，恕不另行通知。

新盟产品

本凭证为新盟产品售后服务的重要依据，请您妥善保管！

销售记录

用户信息	用户姓名		联系电话	
	通信地址及邮编			
	E-mail			
产品信息	产品名称			
	产品编号			
	产品序列号			
	销售商名称			
销售信息	联系地址			
	联系电话		邮政编码	
	生产日期		销售日期	
	销售商印章		发票号码	

维修记录 ●由维修机构填写

维修次数	维修单位	地址	电话	邮编
二				
三				

产品中有毒有害物质或元素的名称及含量

部件名称	有毒有害物质或元素					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)
印刷电路板组件	×	○	×	○	○	○
外壳及部件	×	○	×	○	○	○

○:表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T11363-2006标准规定的限量要求以下。
×:表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T11363-2006标准规定的限量要求。
印刷电路组件，包括印刷电路板及其零部件，电子元器件等。
注：本产品90%以上所用无毒无害原材料得到回收利用，含有有毒有害物质或元素的部件被鉴定技术发展水平和相关法规等有毒有害物质在现阶段可以被替代。

在中华人民共和国境内销售的电子信息产品必须标识此标志。标志内的数字代表在正常的使用状态下的产品的环保使用期限。

感谢您一直对新盟的支持与信赖，请您细心阅读，并妥善保管好本说明书和保修卡，以备您今后的查阅及联系之用。